

# Bump Rubber Cup Installation on RS-15 Series

## Monotube and Twin Tube Adjustable shocks



1. Break the jam nut free and screw eyelet off shock.
2. Screw the adjuster on the eyelet all the way out to full soft. (-)
3. Slide the Bump Rubber cup onto the shaft.
4. With the adjuster at full soft screw the eyelet on shaft until it gets snug.
5. Bring the jam nut down to the eyelet and tighten.
6. Put the clip into the eyelet grove.
7. Squeeze the clip together and position the cup around the eyelet.