

Inflation Tool Instructions

Monotube Shocks



- WITH T-HANDLE BACKED OFF, SCREW GAUGE ON SHOCK (USE CAUTION TO NOT OVERTIGHTEN. OVER TIGHTENING WILL DESTROY THE COPPER GASKET.)
- SCREW T-HANDLE IN TO GET PRESSURE READING
- INCREASE OR DECREASE PRESSURE
- UN-SCREW T-HANDLE
- REMOVE GAUGE FROM SHOCK (A SMALL AMMOUNT OF NITROGEN WILL ESCAPE WHEN YOU LOOSEN THE GAUGE. WE RECOMMEND SETTING YOUR PRESSURE 5 PSI HIGH TO ACCOUNT FOR THIS LOSS.)