

# Bump Rubber Cup Installation on RS-15 Series

Monotube and Twin Tube Non Adjustable shocks



1. Break the jam nut free and screw eyelet and jam nut off shock.
2. Slide the Bump Rubber cup onto the shaft.
3. Screw the Jam Nut back onto the shaft.
4. Position the Adapter Plate over the eyelet and screw the eyelet onto the shaft.
5. With the Adapter Plate sandwiched between the eyelet and the jam nut, tighten the jam nut.
6. Install the clip into the adapter plate groove.
7. Squeeze the clip together and position the cup around the adapter plate.

**COMPETITION *SUSPENSION* INC**

468 SOUTHPOINT CIRCLE SUITE 700 | BROWNSBURG IN, 46112 | 317-858-8775 | CSISHOCKS.COM